



YEELITE

Steam Magic™ Styling Iron

SKU: YLS01

Safety Guide / Guide de Sécurité

Operating Instructions

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS

BEFORE USING

KEEP AWAY FROM WATER

DANGER – Any appliance is electrically live even when the switch is off.

To reduce the risk of death by electric shock:

1. Always unplug appliance immediately after using.
2. Do not use while bathing.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into water or other liquids.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water.

WARNING – To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.
2. Do not pull, twist, or wrap line cord around appliance.
3. This appliance should not be used by, on or near children or individuals with certain disabilities.
4. Use this appliance only for its intended use, as described in this manual. Do not use attachments not recommended by the manufacturer.
5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.
6. Keep the cord away from heated surfaces.
7. Never use while sleeping or drowsy.

8. Never drop or insert any object into any opening.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Unit is hot when in use. Do not let heated surfaces touch eyes or bare skin.
11. Do not place the heated unit directly on any surface while it is hot or plugged in.
12. Do not use an extension cord with this appliance.
13. Do not touch hot surfaces of the appliance.
14. Do not operate with a voltage converter.

CONSIGNES IMPORTANTES DE SÉCURITÉ

Lorsque vous utilisez des appareils électriques, particulièrement en la présence d'enfants, veillez à toujours prendre quelques précautions élémentaires dont les suivantes :

LIRE LE MODE D'EMPLOI AVANT D'UTILISER L'APPAREIL TENIR LOIN DE L'EAU

DANGER – Tout appareil électrique demeure sous tension même si le contact est coupé. Pour réduire les risques de décès par décharge électrique :

1. Débranchez toujours l'appareil immédiatement après l'avoir utilisé.
2. N'utilisez pas l'appareil en prenant un bain.
3. Ne mettez pas ou ne rangez pas l'appareil dans un endroit où il pourrait tomber dans une baignoire ou un évier ou à partir desquels il pourrait être accessible.
4. Ne le mettez pas ou ne l'échappez pas dans l'eau ou dans un autre liquide.
5. Si un appareil tombe dans l'eau, débranchez-le immédiatement; ne le saisissez pas.

AVERTISSEMENT – Pour réduire les risques de brûlure, de feu, de décharge électrique ou de blessure :

1. Ne laissez jamais l'appareil sans surveillance s'il est branché.
2. Ne tirez pas sur le cordon, ne le vrillez pas et ne l'enroulez pas autour de l'appareil.
3. Cet appareil ne doit pas être utilisé par ou pour des enfants ou des personnes ayant certaines incapacités, ou à proximité d'eux.
4. N'utilisez cet appareil que pour l'usage pour lequel il a été conçu, tel que le décrit le présent manuel. N'utilisez pas d'accessoires non recommandés par le fabricant.
5. N'utilisez jamais cet appareil si le cordon ou la fiche est endommagé, s'il ne fonctionne pas bien, s'il a été échappé par terre ou endommagé ou s'il est tombé dans l'eau. Retournez l'appareil à un centre de service autorisé en vue d'un examen ou d'une réparation.
6. Maintenez le cordon loin des surfaces chaudes.
7. N'utilisez jamais l'appareil pendant le sommeil ou si vous êtes en état de somnolence.
8. N'échappez ou n'insérez jamais un objet dans une de ses ouvertures.
9. N'utilisez pas l'appareil à l'extérieur ou là où l'on utilise des aérosols (vaporisateurs) ou administre de l'oxygène.
10. L'appareil est chaud lorsqu'il fonctionne. Faites en sorte qu'aucune surface chaude ne touche vos yeux ou votre peau.
11. Ne posez pas l'appareil chaud directement sur une surface pendant qu'il chauffe ou qu'il est branché.
12. N'utilisez pas une rallonge avec cet appareil.
13. Ne touchez pas aux surfaces chaudes de l'appareil.
14. Ne l'utilisez pas avec un convertisseur de tension.

SAVE THESE INSTRUCTIONS

OPERATING INSTRUCTIONS

POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature. Use on Alternating Current (60 hertz) only. This unit is designed to be operated at 125V AC.

GET TO KNOW YOUR STYLING IRON



Our Steam Magic™ Styling Iron is an innovative product for hair straightening, hair curling and hair moisturizing. Also it has a unique design with silicone layers for heat protection. So your hair will never be hurt by high heat again.

HILIGHTS

- World's first real STEAM IRON.
- Patented technology that can fast converting the water on hair surface into steam and then absorbed by the hair for water replenishing.
- Works perfectly on wet hair, no need to blow dry hair first thus saving time.
- Silicone layers for heat protection that protects the user from burning or scalding on the hair, head or hands.
- Plates with special designed structure, makes the hair to be straightened easily, and have minimum contact with the high temperature plate surface.
- Excellent styling results on both wet and dry hair.
- Super-fast and stable heating technology.
- Professional Iron for everyone to use.
- Up to 450°F (232°C) high heat, adjustable temperatures.

GETTING STARTED

Our Steam Magic™ Styling Iron looks very similar to a regular hair straightener. The purpose is that our customers can easily learn how to use it since they are already familiar with using hair straighteners. However, there are two important things when using our styling iron that are very different with using traditional hair straighteners.

1. When using our styling iron to treat your hair, only need to gently press the upper and lower heating plates on the hair, and allow the hair sliding easily between the two plates. Not like when using a traditional hair straightener you need to clamp down the two heating plates very firmly and press hard on the hair to straighten it. This is because our styling iron has a special rib-shaped structure on both the upper and lower plate surfaces and so is able to automatically straighten the hair during sliding process.
2. When using our styling iron you need to pay attention to the dry-wet status of the hair then slide the iron slowly along the hair from roots to ends with a speed suitable to the hair wet level. Not like for regular hair straighteners you normally need to slide the straightener very fast to avoid burning damage to the hair. This is because our styling iron can convert the water on the hair surface into steam, surrounding the hair, then the steam and water vapor can be fully absorbed by the hair during the sliding process. Since the hair is surrounded by steam for the whole time so it won't be harmed by the hot plates even with a very slow sliding speed.

Once you understand why and how to use our styling iron properly then you can start to use this styling iron to style and care your hair following the detailed instructions in the sections below.

USE YOUR STYLING IRON

1. Hair Straightening on Wet Hair & Hair Moisturizing

Step 1: Our styling iron works perfectly on wet hair. Wet hair will stick together into hair bundles due to water on the hair surface, and will not scatter from each other like dry hair. So how wet should the hair be? Just make the hair to be wet enough but no water dripping to make your clothes wet.

Step 2: Once the iron is powered on and the plates are heated, separate the hair into proper sized but relatively large bundles. Take one hair bundle and carefully place it between the hot plates. Next, gently press down the plates and slide the iron very slowly along the hair bundle all the way from hair roots to ends. We should adjust the sliding speed according to the dry-wet level of the hair. After this first sliding the hair should change from a large bundle to many small bundles that are formed by only a few hairs. Right after the first sliding, we should keep the hair untouched for about 2-3 seconds allowing the hair to fully absorb the water vapor surrounding it. After these 2-3 seconds then we can comb the hair to be ready for step 3.

Step 3: Similar to step 2 we place the hair between the plates and slide for the second time however more quickly this time. The sliding speed again should be adjusted align with the dry-wet level of the hair. Main purpose of this step is to make the hair from small bundles status to be fully separated from each other. Right after this sliding you can feel the hair is a little sticky due to water vapor surrounding it. We then again wait for 2-3 seconds let the hair to absorb the water vapor one more time. After these 2-3 seconds, the hair will no longer has the

sticky feeling and you can comb the hair for several times, the hair will then become soft, smooth, bright, cool, and has a feeling of rich in water content.

2. Hair Straightening on Dry Hair

Our styling iron works excellent on dry hair too. Use our styling iron the same way as using a traditional hair straightener when working with dry hair. The silicone layer wrapping the heating plates will not only protect you from the high heat, but also will provide a soft and steady feeling when doing hair straightening.

3. Hair Curling

To reduce harm to the hair as much as possible during hair curling process, we suggest to moisturize the hair first following the 3-steps process introduced above. Then the next step would be the same curling process as using a regular hair straightener. However, with the added hair moisturizing process with our styling iron, the hair will be rich of water content during the curling process thus will not become too dry after curling.

In addition, for best results and protection of your hair when using our styling iron, we suggest to adjust the hair bundle size and the sliding speed of the iron accordingly with the hair status (dry or wet).

USER MAINTENANCE

Your styling iron is virtually maintenance free. No lubrication or other care is needed. If cleaning becomes necessary, first ensure the styling iron is unplugged and cool then use a slightly damp cloth to clean, then wipe completely dry with a dry cloth. No other cleaning is necessary.

WARNING: Do not immerse in water.

If any abnormal condition occurs, unplug the styling iron, allow it to cool, and return it for repair to an authorized service center only. No repairs should be attempted by the consumer.

STORAGE

When not in use, disconnect the appliance and allow it to cool completely, and store it in a safe, dry location where it will not become damaged, and ensure it is out of reach from children.

Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

LIMITED TWO-YEAR WARRANTY

This product is guaranteed against defects in material and workmanship for a period of 24 months from the date of original purchase.

Should this product become defective during the guarantee period, Yeelite will repair or replace (at our option) your unit free of charge. To obtain service under this warranty, return the defective product to the Yeelite company address listed below, together with your purchase receipt and \$8.00 as the

shipping and handling fee. In the absence of a purchase receipt, the warranty period shall be 24 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24 MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

IN NO EVENT SHALL YEELITE BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

This warranty gives you specific legal rights, and you may also have other rights, which vary from province to province, state to state.

©2017 Yeelite Inc.

53 Goulding Cres., Kanata, ON K2K 2N9, Canada

Visit our web site: www.yeelite.com

Consumer Call Centre Email: info@yeelite.com



20170001 Rev. A

© Copyright 2017, Yeelite Inc. All rights reserved.

Printed in China